
Dial Tone Detector Diagnostic (LD 34)

The Tone and Digit Switch and Digitone Receiver diagnostic program (LD 34) tests cards are used in generating and detecting tones in the SL-1 system. Response to commands for the Dial Tone Detector card are output as DTD messages. Response to commands for the Tone and Digit Switch card are output as TDS messages.

DTD messages

- DTD0001 I s c u "Failure to detect" has exceeded the allowable limit for Dial Tone Detector (DTD) card I s c u.
- DTD0002 I s c u The DTD specified by I s c u has failed to pass the response test.
- DTD0003 Fifty percent of all DTD cards in the system are disabled.
- DTD0004 Test is not specified in configuration.
- DTD0005 Too many messages from DTD specified by TN.
- DTD0006 DTD configured but not used.
- DTD0120 Card is disabled unless 50 percent of the cards are already disabled.
- DTD0121 10 xx DTD card responded incorrectly to tone test. Card sent input message of xx.
- DTD0122 Card failed Dial Tone Detector Test.
- DTD0123 Card did not respond when DTD test was initialized.
- DTD0124 Card did not respond when test tone was applied.